


Spare Parts
Unloader ST-280
Item-No. 20 0280 510



Pos.	Item-No.	Description
1	04 0001 460	Hexagon nut
2	20 0280 490	Hand wheel
3	20 0280 480	Needle bearing
4	01 0004 050	Pressure piece
5	06 0000 750	Spring
6	04 0001 450	Nut
7	04 0001 441	Pin
8	04 0001 400	Piston rod
** 9	05 0001 210	O-ring
**10	05 0001 200	Back ring
11	01 0004 040	Guiding screw
**12	05 0000 550	O-ring
**13	05 0000 061	O-ring
**14	05 0001 230	Back ring
**15	01 0004060	Piston
**16	05 0000 630	O-ring
**17	05 0001 220	Back ring
**18	04 0001 430	Circlip for shafts
19	01 0004 005	Brass housing
# 20	05 0000 020	O-ring

Pos.	Item-No.	Description
# 21	040001410	Valve seat
# 22	040001420	Circlip for bores
# 23	060000010	Stainless steel ball
# 24	060000730	Spring
25	010004010	Inlet nut 3/8" female
26	130000190	Washer
* 27	050000430	O-ring
* 28	040004045	Seal
* 29	050000050	O-ring
* 30	040000440	Valve part
* 31	060000310	Spring
* 32	020001290	Valve housing
* 33	050000580	O-ring
34	010004035	Outlet nut 3/8" female
35	010000355	Plug screw
36	010002575	Plug screw
*	20 0280 650	Repair- Kit „A“
**	20 0280 646	Repair- Kit „C“
#	20 0280 530	Repair-Kit „D“