


Spare Parts

Lance "Push and Pull"

Item-No. 20 0085 500



Pos.	Item-No.	Description
1	01 0002 200	Housing
2	07 0000 110	Lance 760mm
3	07 0000 440	Lance 250mm
4	02 0002 750	Semi casing (1)
5	02 0002 760	Semi casing (2)
6	03 0000 280	Aluminium bar
7	04 0002 885	Straight pin 4x30
8	04 0000 051	Screw 3.5x16
9	20 0085 300	Hose
10	02 0002 770	Cover housing
11	02 0007 500	Hose holder left
12	02 0007 510	Hose holder right
13	04 0002 865	Nut M5
14	04 0002 870	Screw M5x16

Pos.	Item-No.	Description
15	04 0002 880	Straight pin 5x20
16	20 0010 700	Nozzle protection ST-10 black/black
17	02 0007 530	Shrinkdown plastic tube
18	02 0002 780	Clamp (1)
19	02 0002 790	Clamp (2)
20	04 0001 256	Quick coupling plug male
21	01 0005 030	Bracket

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					