


Spare Parts

Lance ST-85 push & pull

Item-No. 200085750



Pos.	Item-No.	Description
1	020002770	Cover housing
2	010002200	Connection part ST-85
3	070000071	Lance ST-85 1200 mm G1/4 m.
4	070000440	Lance 250mm St-85 zinc coated
5	020002760	Semi casing (2)
6	020007510	Hose holder ST-85 right
7	040000051	Screw 3.5x16
8	200085300	Hose G1/4 female - G1/4 male
9	020007500	Hose holder ST-85 left
10	040002865	Nut M5 DIN EN 24032 A2
11	200010700	Nozzle protection ST-10 black/black
12	040002870	Screw M5x16 DIN 7985 A2
13	040002880	Straight pin 5m6 x 20 ISO 2338 A
14	020007530	Shrinkdown plastic tube
15	010005030	Bracket ST-85
16	030000250	Aluminium bar 10x10x1065mm
17	040002885	Straight pin 4m6 x 30 ISO 2338 A
18	020002750	Semi casing (1)

Pos.	Item-No.	Description
19	020002790	Clip (2) ST-85
20	020002780	Clip (1) ST-85

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					